

サンゴーバン

Item No.		Item No.		Item No.		Item No.		Item No.		Item No.		Item No.	
(アンティーク)		S 114 C	×	(ストリーキー)		(フラッシュ)		(オパール)		NEW			
M 1 A	×	S 115 C	△	SY 1 G	△	S 200LT D	×	OP 02 EE	廃	TC 046 C	×		
M 2 A	×	S 116 C	△	SY 2 L	×	S 200MD D	×	OP 04 EE	廃	TY 046 D	△		
M 4 A	×	S 117 A	△	SY 4 G	○	S 200DK D	×	OP 05 EE	廃	TC 063 G	×		
M 6 A	×	S 120 C	×	SY 5 H	△	S 201 E	×	OP 08 EE	廃	TC 076 G	×		
M 9 A	×	S 124 C	×	SY 8 I	×	S 202 E	△	OP 09 EE	廃	TC 121 E	○		
M 10 A	×	S 125 C	×	SY 9 H	×	S 203 E	△	OP 10 EE	廃				
M 13 A	×	S 126 B	×	SY 10 H	×	S 204 E	△	OP 11 EE	廃	(FLKパターン)			
M 14 A	×	S 127 A	×	SY 11 L	×	S 205 E	×	OP 12 EE	廃	FLK 01 A	○		
M 16 A	×	S 129 C	×	SY 12 L	×	S 206 E	○	OP 13 EE	廃	FLK 02 D	○	廃	
M 17 A	×	S 132 C	×	SY 13 I	×	S 207LT D	×	OP 14 EE	廃	FLK 03 D	△		
M 18 A	×	S 133 C	×	SY 14 I	×	S 207MD D	×	OP 16 EE	廃	FLK 04 AA	△		
M 21 A	×	S 135 C	×	SY 15 H	×	S 207DK D	×	OP 17 EE	廃				
S 3 E	×	S 143 A	×	SY 16 H	×	S 208 E	×	OP 19 EE	廃	(FWパターン)			
S 5 C	×	S 144 C	×	SY 17 I	×	S 209 E	△	OP 21 EE	廃	FW 01 C	○		
S 8 C	×	S 150 C	×	SY 18 I	×	S 210 E	×	OP 181 EE	廃	FH 01 D	○		
S 11 C	×	S 151 B	△	SY 20 I	×	S 211 E	×			FK 01 D	○		
S 14 A	×	S 152 A	×	SY 21 I	△	S 212LT E	×						
S 18 A	×	S 155 C	×	SY 22 I	△	S 212DK E	×						
S 25 A	×	S 156 B	×	SY 23 I	×	S 213 E	×	(ニューアンティーク)		(キャセドラル)			
S 30 A	×	S 165 B	×	SY 24 I	×	S 214 D	△			CX 00 A	○		
S 31 A	×	S 166 A	△	SY 25 I	△	S 215 D	×	N 001 A	廃	CX 10 B	○	廃	
S 34 C	×	S 180 E	×	SY 26 G	×	S 216 D	×	N 009 C	廃	CX 12 B	○	廃	
S 39 C	×	S 181 E	×	SY 27 L	×	S 217 D	×	N 013 A	廃	CX 14 C	○	廃	
S 44 A	×	S 182 E	×	SY 28 H	△	S 218 D	△	N 042 A	廃	CX 17 C	○	廃	
S 48 A	×	S 183 E	×	SY 29 L	×	S 219 D	×	N 062 B	廃	CX 23 C	○	廃	
S 51 B	×	S 185 E	×	SY 34 L	×	S 220 D	△	N 122 B	廃	CX 24 C	○	廃	
S 52 C	×	S 186 E	×	SY 35 H	×	S 221 D	×	N 224 A	廃	CX 31 D	○	廃	
S 53 C	×	S 261 A	×	SY 36 G	×	S 222 J	×	N 244 A	廃	CX 32 D	○	廃	
S 54 C	×	S 265 A	×	SY 39 G	×	S 223 J	×	N 300 B	○	CX 34 D	○	廃	
S 56 C	×	S 267 B	×	SY 41 I	△	S 224 K	×	N 1570 A	○	CX 37 B	○	廃	
S 57 C	×	S 270 C	×	SY 42 I	×	S 226 D	×	N 2000 A	○	CX 44 B	○	廃	
S 61 B	×	S 271 C	×	SY 44 G	×	S 227 D	×	N 3315 A	○	CX 47 C	○	廃	
S 62 C	×			SY 45 H	×	S 1176 D	×			CX 67 C	○	廃	
S 65 C	×			SY 50 I	×	S 1186 D	×			CX 71 C	○	廃	
S 66 C	×			SY 51 L	×	S 1187 D	△	(パターンガラス)					
S 68 B	×			SY 52 L	△	S 1225 D	×	TC 042 A	○				
S 70 B	×	(クリアリーミー)		SY 53 I	×			TC 043 C	○				
S 71 B	×	R 1 A	×	SY 55 I	×			TC 060 A	△				
S 72 C	×			SY 56 I	×			TC 061 E	△				
S 77 A	×			S 230 F	△			TC 062 E	△				
S 82 A	×			S 231 F	×			TC 064 D	○				
S 83 A	×	(クリアシーディー)		S 232 F	△			TC 071 C	○				
S 84 A	×	SB 01 A	×	S 233 F	×			TY 071 D	○	フローラガラス			
S 85 A	×			S 234 F	×			TC 072 C	○	F 00 A	×		
S 87 A	×			S 235 F	×			TC 080 D	○	F 01 A	△		
S 89 B	×			S 236 F	×			TC 089 C	○	F 02 B	○		
S 90 C	×			S 237 F	△			TC 097 D	△	F 03 B	○		
S 93 C	×			S 238 F	×	(クラックル)		TC 101 A	○	F 04 B	○		
S 95 C	×	(オバック)		S 239 F	△	CR 1 A	×	TC 113 G	△				
S 97 C	×	OPK 4 F	×	S 661 F	×	CR 3 A	×	TC 115 G	×				
S 98 A	×	OPK 5 F	×	B 1182 F	×	CR 5 A	×	TC 155 A	△				
S 100 A	×	OPK 8 F	×	S 4055 F	×	CR 7 A	×	TC 157 C	○	ガラスファブリック			
S 103 C	×	OPK 9 F	×	BF 06 I	×	CR 8 A	×	TC 159 A	△	ランパーツガラス			
S 104 C	×	OPK 14 F	×	BF 12 I	×	CR 9 A	×	TB 178 D	○				
S 105 C	×	OPK 21 F	×	BF 13 I	×	CR 10 A	×	TC 178 C	○	GAL 001 B	×		
S 106 A	×	OPK 339 F	×	BF 18 I	×	CR 11 A	×	TA 182 H	○	GAL 002 A	○	廃	
S 107 C	×			BF 20 I	×	CR 13 A	×	TC 182 F	○	GAL 003 C	△		
S 108 C	×			BF 152 L	×	CR 14 A	×	TY 182 H	△	GAL 004 E	○		
S 109 C	×					CR 21 A	×	TC 187 C	○	GAL 005 D	○	廃	
S 110 C	×					CR 22 A	×	TC 264 C	○	GAL 006 D	△		
S 111 C	×					CR 180 G	×						