

ランパーツ

Item No.		Item No.		Item No.		Item No.		
(フラッシュ)		(オパック)		(フィッシャーストリーキー)		(ダブル グラス)		
AL	U 1001LT E	△	AL	U 2375 E	△	AL	DP 21 J	×
	U 1001MD E	△		U 2379 E	△		DP 32 F	×
	U 1001DK E	△		U 3464 E	△		DP 33 F	×
	U 1002 F	△		U 3476 E	×		DP 34 J	△
	U 1003 F	△		U 3479 E	△		DP 35 J	×
	U 1004 F	△		U 3515 E	△		DP 43 J	×
	U 1006DK E	○		U 3566 E	△		DP 83 F	△
	U 1007 E	△		U 3581 H	△		DP 98 F	廃
	U 1033 E	○		U 4219 G	△		DP 109 F	×
	U 1042LT I	△		U 4243 E	△		DP 149 F	×
	U 1042MD K	○		U 4333 E	△		DP 192 J	×
	U 1042DK K	○		U 4345 H	△		DP 198 J	△
	U 1047 E	○		U 4352 F	×		DP 202 H	×
	U 1057 E	廃		U 4459 J	△		DP 213 J	×
	U 1058 G	○		U 4464 H	×		DP 214 J	×
	U 1064LT D	○		U 4502 E	×		DP 224 J	×
	U 1064MD D	○		U 4522 E	△			
	U 1064DK D	○		U 4555 G	△			
	U 1066 G	○		U 4563 H	△		(バリゲイト)	
	U 1067 I	×					VJ 64 F	△
	U 1076 E	△	UJ	72 H	○		VJ 157 G	△
	U 1079 E	×	UJ	73 H	△		VJ 158 G	△
	U 2330 E	×	UJ	78 F	○		VJ 159 G	△
	U 3406 E	△	UJ	139 F	○		VJ 160 F	△
	U 3410 H	○	UJ	141 H	△		VJ 161 F	○
	U 3438 E	△	UJ	143 E	○		VJ 166 G	△
	U 3446 E	○	UJ	146 E	○		VJ 191 G	△
UB	U 3446 E	△	UJ	147 F	△		(グラデーシオン)	
U	U 3590 E	△	UJ	148 E	○		GJ 64 F	△
U	U 4631 E	△	UJ	150 E	△		GJ 157 G	△
			UJ	153 E	○		GJ 158 G	○
			UJ	164 E	△		GJ 160 F	×
			UJ	165 F	△		GJ 161 F	×
			UJ	166 F	○		GJ 191 G	△
			UJ	168 F	×			
			UJ	183 F	△		(others)	
			UJ	184 E	△		JU 1 L	×
			UJ	185 E	△			
			UJ	186 F	△		AB 6 L	廃
			UJ	187 E	△		AB 7 L	廃
			UJ	191 E	○		AB 8 K	×
			UJ	194 E	△		AB 12 M	×
			UJ	195 F	○		AB 13 M	×
			UJ	196 E	○		AB 14 J	×
			UJ	231 F	△		AB 16 F	△
			UJ	233 F	△		AB 19 H	廃
			UJ	234 E	△		AB 21 F	廃
			UJ	236 E	○		AB 27 J	△
			UJ	238 K	△			
			UJ	266 E	○		AC 1 F	×
			UJ	315 L	△		AC 6 F	×
			UJ	329 E	△		AC 7 F	×
			UJ	330 F	○		AC 16 L	×
			UJ	332 F	△		AC 24 F	×
			UJ	339 E	○		AC 29 H	×
			UJ	349 F	△		AC 30 H	×
			UJ	351 F	△		AC 37 F	×
			UJ	374 H	△			
			UJ	382 L	△			
			UJ	386 E	△			