

ランパーツ

Item No.				Item No.				Item No.				Item No.			
(フラッシュ)				(オパック)				(フィッシャーストリーキー)				(ダブル グラス)			
AL	U	1001LT E	×	AL	U	2375 E	廃	AL	SJ	4 F	×	AL	DP	21 J	×
	U	1001MD E	×		U	2379 E	廃		SJ	6 F	△		DP	32 F	廃
	U	1001DK E	×		U	3464 E	×		SJ	12 F	×		DP	33 F	×
	U	1002 F	廃		U	3476 E	廃		SJ	13 F	×		DP	34 J	△
	U	1003 F	×		U	3479 E	×		SJ	17 F	△		DP	35 J	×
	U	1004 F	廃		U	3515 E	×		SJ	18 F	廃		DP	43 J	廃
	U	1006DK E	△		U	3566 E	△		SJ	19 F	廃		DP	83 F	△
	U	1007 E	×		U	3581 H	△		SJ	20 F	廃		DP	109 F	廃
	U	1033 E	△		U	4219 H	廃		SJ	25 F	廃		DP	149 F	×
	U	1042LT I	×		U	4243 E	廃		SJ	26 F	△		DP	192 J	×
	U	1042MD I	×		U	4333 E	×		SJ	27 F	廃		DP	198 J	△
	U	1042DK K	×		U	4345 H	廃		SJ	29 F	×		DP	202 H	廃
	U	1047 E	×		U	4352 F	×		SJ	31 J	△		DP	213 J	廃
	U	1058 G	×		U	4459 J	廃		SJ	34 J	×		DP	214 J	×
	U	1064LT D	×		U	4464 H	廃		SJ	36 F	廃		DP	224 F	×
	U	1064MD D	×		U	4502 E	×		SJ	39 F	廃				
	U	1064DK D	△		U	4522 E	×		SJ	41 F	廃				
	U	1066 G	×		U	4555 G	×		SJ	42 F	廃	(バリゲイト)			
	U	1067 I	△		U	4563 H	廃		SJ	44 F	×		VJ	64 F	×
	U	1076 E	廃		U	4631 E	○		SJ	45 F	廃		VJ	157 G	△
	U	1079 E	廃		UJ	72 H	×		SJ	46 F	×		VJ	158 G	△
	U	2330 E	×		UJ	73 H	×		SJ	48 J	×		VJ	159 G	△
	U	3406 E	廃		UJ	78 F	×		SJ	54 I	×		VJ	160 F	△
	U	3410 H	廃		UJ	139 F	×		SJ	55 I	×		VJ	161 F	廃
	U	3438 E	×		UJ	141 H	△		SJ	56 I	廃		VJ	166 G	△
	U	3446 E	△		UJ	143 E	×		SJ	57 I	×		VJ	191 G	△
UB		3446 E	×		UJ	146 E	×		SJ	58 I	×				
U		3590 E	×		UJ	147 F	×		SJ	61 F	×				
					UJ	148 E	×		SJ	152 F	×	(グラデーション)			
					UJ	150 E	廃		SJ	198 F	△		GJ	64 F	×
					UJ	153 E	×		SJ	242 F	△		GJ	157 G	廃
					UJ	164 E	廃		SJ	243 F	×		GJ	158 G	△
					UJ	165 F	×		SJ	244 F	×		GJ	160 F	廃
					UJ	166 F	×		SJ	245 G	△		GJ	161 F	×
					UJ	168 F	△		SJ	247 G	△		GJ	191 G	廃
					UJ	183 F	×		SJ	258 G	△				
					UJ	184 E	×		SJ	259 F	×				
					UJ	185 E	廃		SJ	269 G	△	(others)			
					UJ	186 F	△		SJ	277 F	廃		JU	1 N	×
					UJ	187 E	×		SJ	282 F	△				
					UJ	191 E	△		SJ	300 J	廃		AB	8 K	×
					UJ	194 E	×		SJ	324 G	×		AB	12 M	廃
					UJ	195 F	△		SJ	383 J	廃		AB	13 M	廃
					UJ	196 E	廃		SJ	419 I	△		AB	14 J	廃
					UJ	231 F	×		SJ	622 J	×		AB	16 F	廃
					UJ	233 F	廃		SJ	652 J	×		AB	27 J	廃
					UJ	234 E	廃								
					UJ	236 E	廃						AC	1 I	△
					UJ	238 K	廃						AC	6 F	×
					UJ	266 E	×						AC	7 F	廃
					UJ	315 L	△						AC	16 L	廃
					UJ	329 E	×						AC	24 F	廃
					UJ	330 F	×						AC	29 H	廃
					UJ	332 F	×						AC	30 H	廃
					UJ	339 E	×						AC	37 F	廃
					UJ	349 F	×								
					UJ	351 F	×								
					UJ	374 H	△								
					UJ	382 L	×								
					UJ	386 E	×								